

Testing SOG chips with the Logic Analyzer

Introduction

In this document we describe how a Sea-Of-Gates chip in a DIL40 package can be tested with the logic analyzer LA-5580. The purpose is to verify if, given a set of input patterns, the tested device produces the same output patterns as a set of reference output patterns.

A logic analyzer is an instrument that is similar to an oscilloscope: both instruments measure output signals (voltage) as a function of time after some trigger moment. However, important difference are:

- A logic analyzer usually only measures two different signal levels: high and low.
- A logic analyzer is capable of measuring a large number of output signals (e.g. 80).
- Besides measuring output signals, a logic analyzer can simultaneously apply input signals.

The logic analyzer LA-5580 is a hardware box that is controlled (via a USB connection) by a graphical interface program LA5000 that is running a PC. A picture of the interface is shown in Figure 1




Figure 1: Graphical Interface for the Logic Analyzer LA-5580

Overview

As input we need a file with reference input and output patterns (.ref file) and a file with information about how the pins of the design are connected to the pins of IO buffers of the chip (.buf file). Typically, both these files have been produced during the design of the chip. Using the program test_flow, these files are converted into a pattern (.csv file) and an initialization (.ini) file that can be used as input for the logic analyzer program, and a scheme that shows how the pods of the logic analyzer should be connected to the pins of the package of the SOG chip. Then, via the logic analyzer program LA5000, the logic analyzer is used to send the input patterns to the tested SOG device and to collect the resulting output patterns. Finally, the program test_flow is used to compare the measured output patterns against the reference output patterns.




Figure 2: The different steps for testing

Obtaining the Reference Files

Copy the relevant .ref and .buf files that you have created during the design phase to a writable directory on the local disk of your PC (e.g. C:\wpstmp). Note that it is important to store the files on the local disk because otherwise the logic analyzer software may have problems to read it. Note that

the desktop of the PC is usually not on the local disk in our environment.

Preparing the Input Data for the Logic Analyzer

Start the program test_flow (T:\ET2805\common\test_flow.tcl). Next click Commands → Read_reffile and open the .ref file. If the same directory contains a .buf file, you will be asked if it is ok to update the information with this file. In that case, click yes. Otherwise click Commands → Update_with_buf file and open the appropriate .buf file. To create a window with input patterns and output patterns in csv format, click Commands → Make_csvfile. In the new csv window, use the command File → Save_csvfile to create the data files that can be used as input for the logic analyzer.

A wiring scheme for how to connect the clips of the wires of the pods to the pins of the SOG device can be obtained by first selecting the appropriate bondbar number for the package in the upper right corner of the test_flow window and next using the command Commands → Show_pod_connections.

Setting up the Logic Analyzer

Connect the USB cable of the logic analyzer LA-5580 to the upper USB port at the front of your computer. Plug in the pattern generation pods Pod 1A, Pod 2A, etc. in the lower connector rows (label "board 1") of the analyzer and the logic (measurement) pods Pod 1B, Pod 2B, etc. in the upper connector rows (label "board 2") of the analyzer. Note that the pods have numbers on them. Plug Pod 1 in the leftmost connector, Pod 2 in the second leftmost connector etc.

Mounting and connecting the SOG chip

Mount the SOG package on the DIL40 connector box. From the separate IC testbox, connect GND (0 Volt) and VDD (5 Volt) to the appropriate connector holes on the DIL40 connector box, using cables with 4mm plugs. Connect the clips of the wires of the pods to the pins of the SOG package according to the device-wiring scheme that was generated using test_flow. Connect at least one black wire of each pod to the GND signal. The pod input Pod 1B(0) at channel 0 will be used as a trigger signal for the acquisition of data and should directly be connected to an output of a pattern generation pod. This connection is given at the bottom of the wiring scheme that was obtained using test_flow.

Switch on the power supply for the SOG chip and switch on the power supply for the logic analyzer. Be careful to only reconnect wires to the pins of the device when the power supply for the SOG chip is switched off.

Using the Logic Analyzer

Start the Logic Analyzer control program LA5000 Logic Analyzer. If the Timing view window is not yet shown, click Timing → Timing window.

Besides the .csv file that was created by test_flow, also a .ini file with the same base name was created by test_flow. Click File → Open to first open the file .ini file that was created by test_flow.

Next, click View → Clear Data Buffer to clear all signals. Then, click File → Open to open the .csv file that was generated using test_flow. The option Type 2 CSV file must be enabled during this. After reading the .csv file you will see the reference output signals in the Timing window and you may inspect the input signals when you click Pod → Edit Pattern Generator Data (or button EDIT PAT). The reference output signals will be overwritten when capturing analysis data from the logic analyzer.

Then, click Trigger → Go or the Go button to start the analysis. The output of the analysis will appear in the Timing view window.

To prepare for a more exact comparison using the program test_flow, export the output signals using File → Export. For the Data field, select "Group outputs" and select Binary, click OK, and then save the file as type "Comma Sep (.CSV)".

Comparing the Analyzer Output with the Reference Output

In test_flow, click on Commands → Compare. Next, in the compare window, click File → Compare csv and select the .csv file that was created using the Logic Analyzer. After the file has been read, the measured output signals will be compared against the reference output signals, just before every rising clock edge. On each line you will see from left to right: the time, the clock period number, the input signals, the reference output signals and the measured output signals. In case the reference outputs and measured outputs are different, they have a red colour. You can click on a line to list the different output vectors below each other. If you click on a column in this list, the name of the corresponding output terminal will be highlighted at the sub window at the right. You can use commands from the Commands button in the compare window to navigate through the errors.

Default, all output signals and all inout signals will be compared. By disabling the toggle button inout, only output signals will be compared.

Trouble Shooting

When the output signals are not according to as expected, carefully check all pod connections. Further you can try to lower the sample rate Thirdly, you can try another IC.

Further Reading

LA 5000 Logic Analyzer Software Manual (see OP Course Documents on blackboard)
Logic Analyzer LA-5000 series, Link Instruments Inc (<http://linkinstruments.com>)